

Installation Instructions

Part Number 571713

Road Defender Rear Window Bars

2011-2016 Ford Interceptor Utility

Parts List				Tools Required	
Item	Qty.	Part No.	Description		
1	1	571713 D	Driver Side Window Bar	#2 Phillips Driver Bit	
2	1	571713 P	Passenger Side Window Bar	Drill Motor	
3	26		#8 x 3/4" Self Drilling Screw		



Read the installation instructions completely and verify that all of the parts listed are accounted for. If you have defective, missing or damaged parts or need assistance, please contact *Go Rhino Products* for fast, friendly customer service at: 1-888-427-4466 or email: warranty@gorhino.com

Installation

Step-1 Open the driver and passenger side rear doors and roll down both rear windows.

Step-2 Beginning with the passenger side position and align the window bar mounting frame with the door frame.

Step-3 With the window bar in place install the self-drilling screws starting at the bottom on each side first, and then work up each side to install the remaining screws. Repeat step 2 & 3 for the driver side.